

INSTRUCTION MANUAL

PNEUMATIC BOX FOR SIMPLE EXTRUSION GROUP

106 004

Manual: 574.095.112 - 1310

Date : 31/10/13 - Supersede : 03/11/11

Modif. : Page 4 (112 cycles → 1/2 cycle)

TRANSLATION OF THE ORIGINAL MANUAL

IMPORTANT: Before assembly and start-up, please read and clearly understand all the documents relating to this equipment (professional use only).

THE PICTURES AND DRAWINGS ARE NON CONTRACTUAL. WE RESERVE THE RIGHT TO MAKE CHANGES WITHOUT PRIOR NOTICE.

KREMLIN - REXSON

150, avenue de Stalingrad 93 245 - STAINS CEDEX – France 33 (0)1 49 40 25 25 Fax: 33 (0)1 48 26 07 16


www.kremlin-rexson.com




INSTRUCTION MANUAL PNEUMATIC BOX FOR SIMPLE EXTRUSION GROUP

TABLE OF CONTENTS

A. STARTING UP	3
B. INSTRUCTIONS WHEN REMOVING THE DRUM	4
C AD HISTMENT OF THE ANTI OVERSDEED	1





A. STARTING UP

NOTA: The anti overspeed are preset in the factory; if you need to change them, refer to section C.

- 1 Open the main air inlet valve (2); the "UNDER PRESSURE" indicator light (4) becomes green.
- 2 Place the key switch (10)"WORK 1-DRUM REMOVAL" on "REMOVAL DRUM",
- 3 Push the button (9) "POWER RESET". Check the indicator lights :
 - > "UNDER PRESSURE" indicator light (4): green colour,
 - > "PUMP FAULT" indicator light (14): red colour,
 - > "DOWN" indicator light (6): white colour.
- 4 Unscrew the priming rod (3),
- 5 Install air pressure on the elevator by means of the regulator (5) (minimum: 4 bar / 58 psi; maximum: 6 bar / 87 psi); check by means of the gauge (15).
- 6 Lift the follower plate (16) in up position by means of the "UP" control button (12).

The elevator is in up position:

- 7 Open the drum clamping,
- 8 Place the material drum under the follower plate (16); take off the drum cover,
- 9 Reclamp the drum.

Down procedure:

- 10 Push the "**DOWN**" button (8) to make the follower plate go down (the adjustment of the follower plate down speed is carried out by means of the regulator (5) adjusting the elevator air pressure),
- 11 As soon as the plate is on the drum, air under the plate is exhausting from the priming rod hole,
- 12 Wait until material flows from the priming rod,
- 13 Install the priming rod (3),
- 14 Check on the regulator (18) that pump (17) pressure is equal to 0 bar / 0 psi,
- 15 Open the drain valve (1) of the pump,
- 16 Reset the pump pushing the "PUMP RESET" button (13),
- 17 Adjust progressively the pump (17) pressure by means of the regulator (18) to prevent the pump racing,
- 18 Let flow material from the drain, wait until there is no more air,
- 19 Close the pump drain valve (1),
- 20 Place the key switch (10) "WORK 1-DRUM REMOVAL" on "WORK",
- 21 Check the air pressure on the gauge (15); adjust it if necessary by means of the regulator (5),
- 22 Push the "DOWN" push button (8); the "DOWN" indicator light (6) becomes green,
- 23 Drain the distribution circuit by means of the material filter drain valve and of the gun opening.

B. INSTRUCTIONS WHEN REMOVING THE DRUM

After stopping the alarm pushing the "STOP ALARM" knob, please follow the instructions hereafter:

- 1 The follower plate (16) is in low position; the **"PUMP FAULT"** indicator light becomes red (a pre end of drum information can signal previously the end of drum : electric information),
- 2 Place the key switch (10) "WORK 1-DRUM REMOVAL" on "DRUM REMOVAL",
- 3 Install the follower plate pushing the "UP" push button (12) while injecting air with the "EXTRACTOR" push button (11),

Never push more than several seconds the **"EXTRACTOR"** push button.

- 4 When the follower plate is in up position, clean the seal,
- 5 Unclamp the drum, take it off and change it,
- 6 Follow the start up procedure from the A7 stage to the A22 stage.

C. ADJUSTMENT OF THE ANTI OVERSPEED

That adjustment is carried out with the pump running light, without material.

- 1 Open the box,
- 2 Unscrew the 2 knurled screws from the 2 tempos,
- 3 Adjust the pump to the maximum wanted speed by means of the mano regulator (18) (around 1/2 cycles/sec 1 cycle = 1 return),
- 4 Screw the knurled screw of the low tempo until you get an escape noise (time base),
- 5 Screw the knurled screw of the up tempo until you get the tripping of the anti overspeed,
- 6 Unscrew the 2 screws (2 turns) counterclockwise,
- 7 Reset the pump by means of the "PUMP RESET" knob (13) then refine the adjustment if necessary,
- 8 Lock the 2 screws by means of the lock nuts,
- 9 Check the adjustment increasing the pressure in the moto pump by means of the mano regulator (18).

GESTION_MONTEE-BAISSE_VERIN

BOIS PERRIN VISA TEL 01.49.35.23.23 FAX 01.49.35.23.33 5 RUE MONTGOLFIER 93116 ROSNY SOUS 14/11/01 VOTRE PARTENAIRE EN AUTOMATISME ORIGINAL - FESTO FRANCE LIVRAISON / MISE A JOUR LIVRAISON INDICE

24 Avenue AMPERE Z.I. Villemilan 01 60 13 59 00 91320 WISSOUS 20 81 01 69 ADRESSE e-mail FAX TEL

REXSON

SOCIETE:

RESPONSABLE TECHNIQUE: M.BATICLE

R-106004 N° PROJET


N° SERIE:

: 03.87.95.97.50 03.20.62.94.94 04.72.05.66.00 : 02.40.48.98.00 05.57.26.19.00 AGENCES FESTO FRANCE SARREGUEMINES VERIFIE PAR : BORDEAUX NANTES SECLIN LYON : J-Jacques PERRIN : Carlos MARTINS : J-Jacques PERRIN : J-Loup HARY CONSEILLER TECHNIQUE : Yann CREZE : client ASSISTANT TECHNIQUE INTERVENANTS FESTO RESPONSABLE PROJET RESPONSABLE DAO SERVICE : ESA MISE EN ROUTE REALISATION


PAGE


	DESIGNATION FOLIO		INDICE	DESSINATEUR	DATE
1 IMPL/	IMPLANTATION COFFRET		A	PERRIN	14/11/01
2 IMPLA	IMPLANTATION COFFRET		A	PERRIN	14/11/01
3 SCHEN	SCHEMA PNEUMATIQUE		А	PERRIN	14/11/01
4 SCHEN	SCHEMA PNEUMATIQUE		А	PERRIN	14/11/01
					4) µ
DESCRIPTION PROJECT :	TON GESTION_MONTEE-BAISSE_VERIN	SOCIETE : REXSON			

NO FOLIO	DESIGNATION FOLIO		INDICE	DESSINATEUR	DATE	
1	NOMENCLATURE	A		PERRIN	14/11/01	
2	NOMENCLATURE	A		PERRIN	14/11/01	
3	NOMENCLATURE	A		PERRIN	14/11/01	
	a a					
					~=;	
	DESCRIPTION GESTION MONTEE-BAISSE VERIN SO	SOCIETE : REXSON				
						- 10101



В В В В В В В В В В В В В В В В В В В		FESTO LICALISATION F010 Coffeet 2
97 08 10 11 12 13 16 17 18 19 20 23 23 24 25 26 27 28 39 39	WIND DE DESSOURS WATER DE	A PERRIN 14/11/01 RESSEPTION GESTION MONTEE/BAISSE VERIN SOCIETE : REXSON FEERFRET IN REDIET : R-106004
00 01 04 03 06		ECH 1:2





REPERE	QTE	DESIGNATION	TYPE	REFERENCE	FABRICANT	COMMENTAIRE	IRE
20	1	REPARTITEUR	FR-12-PK3-B	8761	FESTO		
-601	1	COFFRET AVEC PLATINE 500 400 210 RA	RAL7032 ACIER AE1045.600	AE1045.600	RITTAL	COFFRET	
	п	CHASSIS	NRRQ-2N	9365	FESTO	COFFRET	
PE1 a PE2	2	PRESSE ETOUPE + ECROU	PG07	260770+240702	CAPRI		
PE3 a PE4	2	PRESSE ETOUPE + ECROU	PG11	261170+241102	CAPRI		
30	-	TRAVERSEE DE CLOISON	8-550	153159	FESTO		
31 a 33	6	TRAVERSEE DE CLOISON	4-858	153157	FESTO		
35							
37 a 40							
45							
34	2	TRAVERSEE DE CLOISON	9-550	153158	FESTO		
42							
41	-	TRAVERSEE DE CLOISON	SCM-1/4	9971	FESTO		
	-	RACCORD	0S-1/4-8	153005	FESTO		
Н07	1	ELEMENT SONORE	XVB-C9B	XVB-C9B	TELEMECANIQUE		
16	2	BOUTON POUSSOIR NOIR	T-22-SW	9289	FESTO	MONTEE VERIN	
18 a 19							
21							
s70							
	5	DISTRIBUTEUR TABLEAU	SV-3-M5	6817	FESTO	MONTEE VERIN	
17	1	BOUTON POUSSOIR ROUGE	T-22-R	7666	FEST0	ARRET DESCENTE	
A PERRIN	14/11/01	DESCRIPTION GESTION_MONTEE-BAISSE_VERIN	SOCIETE : REXSON		758770	LOCALISATION	Ĭ.
+		DESCRIPTION		3-			Н

REPERE	QTE	DESIGNATION	TYPE	REFERENCE	FABRICANT	COMMENTAIRE	RE
	П	DISTRIBUTEUR TABLEAU	SV-3-MS	6817	FESTO	ARRET DESCENTE	
22	1	TETE SELECTEUR 2 POSIT A CLEF 45	282-8G2	ZB2-BG2	PARKER	TRAV-CHANG	
	7	DISTRIBUTEUR DE BASE 3/2 NF	PX8-81011	PXB-81011	PARKER	TRAV-CHANG	
	П	DISTRIBUTEUR ADDITION.DE BASE 3/	PXB-B1921	PXB-81921	PARKER	TRAV-CHANG	
520	-	BOUTON POUSSOIR JAUNE	T-22-6	9290	FESTO	REA PUISSANCE	
	Н	DISTRIBUTEUR TABLEAU	SV-3-MS	6817	FESTO	REA PUISSANCE	
15	1	MANO DETENDEUR	LR-1/4-D-MINI	159625	FESTO		
	п	MANOMETRE DE PRECISION TABLEAU	FMA-40-10-1/4-EN	159596	FESTO		
46	1	DETENDEUR	LRMA-1/8-Q54	153489	FESTO		
12	2	CONVERTISSEUR	PE-1/8-2NX2	13691	FESTO		
72		•					
001	1	LIMITEUR DE DEBIT	GR-M5-B	151213	FESTO		
a 7	2	DISTRIBUTEUR PNEUMATIQUE	VL/0-3-PK3x2	4245	FESTO	VL0 1	
01	ч	DISTRIBUTEUR PNEUMATIQUE	VL-5/3E-1/4-B	14297	FESTO		
20	2	DISTRIBUTEUR PNEUMATIQUE	VL/0-3-1/8-B	7803	FESTO	7803	
48							
03	1	DISTRIBUTEUR PNEUMATIQUE	J-5-PK3	4503	FESTO		
04	2	DISTRIBUTEUR PNEUMATIQUE	J-3-PK3	10772	FESTO		
7.1	romalinus						
05	1	SOUPAPE DE REGLAGE	VD-3-PK3	9270	FESTO		
70	-	GENERATEUR D'IMPULSION	VLK-3-PK3	9639	FESTO		
2	10/11/41	BESCRIPTION GESTION MONTEE-RAISSE VEBTN	SOCIETE : RFXCON				
E 1	10/11/21	DESCRIPTION	100VA			LOCALISATION	Fo 10

REPERE	QTE	DESIGNATION	TYPE	REFERENCE	FABRICANT	COMMENTAIRE
	Н	BATTERIE DE FONCTION OU	0S-PK-3-6/3	4232	FESTO	
a 55	2	ELEMENT FONCTION OU	0S-PK-3	6684	FESTO	
a 52	2	SILENCIEUX	U-1/4-B	6842	FESTO	
	2	TRAVERSEE DE CLOISON	QSSF-1/4-8B	153166	FESTO	
	П	SILENCIEUX	U-1/4-B	6842	FESTO	
	1	TEMPORISATEUR	VZ-3-PK3	5755	FESTO	0.25-5sec
	1	TEMPORISATEUR	VZ0-3-PK3	5754	FESTO	0.25-5sec
a H11	2	VOYANT PNEUMATIQUE	OH-22-VERT	4237	FESTO	DESCENTE EN COURS
	1	VOYANT PNEUMATIQUE	OH-22-ROUGE	4131	FESTO	DEFAUT
	1	ACCESSOIRES SUIVANTS :			FESTO	
	4	GOUJON	GOUJON M8x30 (50)	O) GOUJON	FESTO	
						V
						ă a
PERRIN	14/11/01	DESCRIPTION GESTION_MONTEE-BAISSE_VERIN	SOCIETE : REXSON			LOCALISATION FOlio
		DESCRIPTION				