



PRESSURE TANK

PREVENTIVE MAINTENANCE

TRANSLATION OF THE ORIGINAL MANUAL

IMPORTANT : Before assembly and start-up, please read and clearly understand all the documents relating to this equipment (professional use only).

THE PICTURES AND DRAWINGS ARE NON CONTRACTUAL. WE RESERVE THE RIGHT TO MAKE CHANGES WITHOUT PRIOR NOTICE.

KREMLIN - REXSON

150, avenue de Stalingrad

93 245 - STAINS CEDEX – France

☎ : 33 (0)1 49 40 25 25 **Fax** : 33 (0)1 48 26 07 16

www.kremlin-rexson.com

■ **SPRAY GUN**

Comply with the usual instructions of spray gun servicing (refer to spray gun instruction manual).

■ **TANK**

Make sure that the suction strainer is clean and in good condition.

If the tank is equipped with a pneumatic agitator, each day, before starting-up, remove the plug from the air motor and inject some oil drops into the port and reinstall the plug (refer to agitator instruction manual).

**Whatever the case, when stopping the tank, always leave it filled with material.
For a short duration shutdown, if the flushing has not been carried out, leave the pump filled with material.
For a long duration shutdown, after flushing the pump, leave it filled with solvent.**